Heat Shoe Threading Diagram

- Load and thread the laminating film so that the film side (the "shiny" side) is next to the heat shoe.
- The adhesive side (the "dull" side) should face you.
- When threading the laminator, make sure the film and threading board go between the back set of rubber rollers.



