



High-quality point of sale graphics are made simple with D&K's Universal Sign Pouch System. Use your regular printer and a desktop laminator to easily produce window, floor, and countertop graphics without the need for bulky supply rolls or large equipment. Universal sign pouches feature a textured vinyl laminate that meets U/L 410 requirements for floor graphic slip resistance. The reverse side includes a removable adhesive designed to work on floors, windows, and countertops without damaging the surfaces.

## Instructions for Making Signs:


- Insert a printed image inside a pouch and place into the provided release folder.
- Feed the release folder into a heated roll laminator and retrieve from the back when cool.
- Remove the pouch and trim off excess material.
- Peel back the protective release liner to expose the adhesive. Moving from the center of the graphic outwards, use a squeegee or similar object to apply pressure that smooths out any trapped air pockets.



Floor/Countertop Graphics



Window Graphics (Inside)



Window Graphics (Outside)

## Recommendations

- 1) Always use a release folder when processing pouches through a laminator. The release folder will help protect your equipment from any potential adhesive overflow.
- 2) Ensure that the surface you are mounting to (window, floor, countertop) is completely free of dirt and other contaminants. Any debris may be visible or appear as a bubble trapped underneath the graphic.
- 3) Use two-sided prints for window graphics that can be viewed from the front and back.

## Universal Sign Pouch System

### Textured Vinyl Side (FGK)

The textured vinyl surface meets U/L 410 requirements for floor graphic slip resistance. This layer adds protection and rigidity to your prints while reducing glare from the sun and other light sources. The SuperStick® adhesive on this layer will stick to most digital prints and also features UV inhibitors to help prevent graphics from fading.

### Mounting Adhesive Side (OSR)

Display pouches feature a two-sided adhesive system. One side contains a heat-activated adhesive that sticks to your print. The other side offers a removable pressure sensitive (cold-application) adhesive protected by a disposable liner. This adhesive surface can be removed from windows, floors, and counters without damage for a period of six months.



### Universal Sign Pouch System

Part #	Pouch Size	Pouches/Box
USP9X12	9" x 12"	10 ea.
USP12X18	12" x 18"	10 ea.
USP185X245	18.5" x 24.5"	10 ea.
USP245X365	24.5" x 36.5"	10 ea.